INSTALLATION INSTRUCTIONS

PSB-2244

DISPLAY MOUNTING BRACKET

Prior to assembly, unpack carton completely and verify contents.
If you are missing any of the following components, please contact Customer Service at 1-800/582-6480



Figure 1

(2) Plasma Upright Brackets
(4) Mounting Button - Tapped
(4) M10 x 50mm Hex Head Cap Screw
(4) .750 x .390 x 1.00 Nylon Spacer
(1) 1/8 Allen Key
(2) Plasma Top/Bottom Bracket
(8) 10-24 x .5 Button Head Cap Screw
(4) M15 x M10.4 x M20 Nylon Spacer
(1) Wrench, Hex, 17mm

BEFORE PROCEEDING, READ INSTALLATION INSTRUCTIONS COMPLETELY

CAUTION! **DISPLAYS ARE EXTREMELY FRAGILE.**

WARNING! **ALL COMPONENTS MUST BE SECURELY FASTENED TO A STRUCTURAL MEMBER CAPABLE OF SUPPORTING 4 TIMES THE COMBINED WEIGHT OF ALL COMPONENTS PLUS THE EQUIPMENT BEING MOUNTED. IF IT CANNOT SUPPORT THIS WEIGHT, THE STRUCTURE MUST BE REINFORCED.**
THE MAXIMUM WEIGHT TO BE INSTALLED ON THE MOUNT IS 175 POUNDS (79.38 KG).

1. Using a 10-24 button head cap screw inserted from back side of bracket, secure mounting button, with chamfered hole of mounting button (larger surface) facing bracket, to upright brackets (four places) (see Figure 2 & Figure 3).



Figure 2



Figure 3

CHIEF
Ideas Supporting Ideas
CHIEF MANUFACTURING INC.
1-800-582-6480 952-894-6280 FAX 952-894-6918
8401 EAGLE CREEK PKWY, STE. 700
SAVAGE, MINNESOTA 55378 USA

8804-000302 REV. E
2008 Chief Manufacturing
www.chiefmfg.com
2/08

2. Using four 10-24 button head cap screws, attach uprights to top/bottom brackets (see Figure 4 & Figure 5).



Figure 4



Figure 5

3. Place Nylon spacers over mounting holes on back of screen. Attach mounting brackets to display using M10 screws (see Figures 6 & Figure 7). Use the nylon spacer that works best for your screen.

4. With the aid of another person, lift your display up to the Chief Mount, aligning buttons of mounting brackets with slots in the Chief Mount.

5. Lower safety latch on the Chief Mount to secure your display, making sure latch is completely engaged.



Figure 6



Figure 7